

PACER
MASTER MACHINE INTERFACE DOCUMENTATION
FOR
MCI JH LLO

DOCUMENTATION RELEASE : 860901

MACHINE INFORMATION

MACHINE TYPE : MCI JH 110
REMOTES : NONE TESTED
MASTER LIMITATIONS : NONE
TIME CODE CHANNEL : ANY
HIGH SPEED CODE : NONE

TACH FEATURES

TACH Format : TACH + DIR
TACH Frequency : 32 Hz at 15 ips
Direction Signal : LOW = FORWARDS, HIGH = REVERSE
TACH Output Drive : TRANSISTOR
TACH Pulse Shape : SQUARE

MACHINE MODIFICATION : NONE REQUIRED

REMARKS



ATTENTION



Some Pacer machine cables have the same
connector at both ends.

Please note that all Pacer cables have a label
consisting of a cable part number at the end which
you should connect to the rear of PACER

Please ensure that you connect it
the right way round !