

Operating Manual

Lynx

Console Control Unit

Assistance and Information

TimeLine

1755 La Costa Meadows Drive
Suite B
San Marcos, CA 92069

Technical Support

Phone: (760) 761-4440
Fax: (760) 761-4449
SUPPORT@TIMELINEVISTA.COM

Software Version

Serial Number

Remember, when calling for technical support, you must provide the software version and CCU serial number so that we can give you accurate and prompt assistance.

Printing History

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means electronically, mechanical, photocopying, recording or otherwise, without the prior written permission of TimeLine Vista, Inc.

Each revision will cause the letter to the right of the manual part number to change. The purpose for each revision will be listed below. Events such as the addition of a feature or functional test will cause the revision number to change.

Internal Document Number: 73K010 Revision E

Revision Number	Approval Date	Serial No. Affected	Changes Made
C	2/18/93	N/A	Revised Figure 3-8 in Installation Section.
D	3/29/93	N/A	Remove "Required Cables" table in Installation Section.
E	9/12/94	N/A	Revised Neve Installation (page 3-18 and 3-24)

Limited Warranty

TimeLine Vista, Inc. (TimeLine) warrants this product against defects in material or workmanship as follows:

1. For a period of ninety (90) days from the date of purchase TimeLine will at it's option, either perform necessary repairs at it's expense or pay the labor charges of others it authorizes to repair the defective product. After the initial 90 day period labor charges are the responsibility of the purchaser.
2. In addition TimeLine will supply at no charge, new or rebuilt replacements for defective parts for a period of one (1) year from the date of purchase.

Labor and Parts

To obtain warranty service, the purchaser must notify TimeLine in writing during the initial ninety (90) day period. TimeLine will then authorize the purchaser to take or deliver, prepaid, the product to TimeLine or it's authorized Service Center.

Parts Only

During the remainder of the warranty period, any defective part will be replaced if the purchaser will take or deliver the product, prepaid to TimeLine. Labor incurred in the repair is at the purchaser's expense.

This Warranty does not cover any damage due to accident, misuse, abuse, or negligence.

We suggest that the purchaser retain the dated sales receipt as evidence of the original date of purchase.

This warranty is not transferrable and applies only to the original, registered purchaser.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. TIMELINE SHALL NOT BE LIABLE FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, AND EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE. TIMELINE EXPRESSLY DISCLAIMS ANY WARRANTY, EXPRESS OR IMPLIED, OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

USA: Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitation and exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Safety

To assist identification of potentially hazardous circumstances or procedures, warnings and cautions will be displayed with the appropriate text. Occasionally, information that provides an enhanced understanding of the text will be provided with a Note.

Note

A Note provides information about or an explanation of a topic related to the subject being discussed.

Caution

Cautions describe procedures or equipment where personal injury may occur if the procedures are not performed precisely as specified.

Warning

Warnings describe a procedure that if not followed as specified could potentially cause damage to the equipment, a loss of data, or create an error condition.

Manual Contents and Use

To use this manual effectively, first review the applications and system configurations presented in the Applications chapter to determine your requirements and preferences.

Then use the Installation chapter to install the Lynx Console Control Unit (CCU) and make the correct equipment connections. Follow the initialization and start up tutorial described in the Getting Started chapter to get a "hands-on" demonstration of the CCU's capabilities.

If you experience any difficulties, refer to the System Verification and Troubleshooting chapter to analyze the problem. Refer to the subsequent chapters for detailed information about each of the CCU functions and general concerns.

The chapter contents are as follows:

Introduction	Provides a high level overview of the Console Control Unit, and feature list.
Applications	Presents common applications and configurations for Console Control Unit, audio, and video equipment.
Installation	Describes how to install and configure the CCU for your system.
Getting Started	Presents initialization, start up procedures, and basic operating instructions.
System Verification & Troubleshooting	Describes methods to verify that your system is correctly installed and troubleshooting procedures to isolate parts of the system which may be incorrectly configured or installed.
Features and Controls	Contains a description of the front panel LEDs and keys on the Console Control Unit (CCU). The descriptions are grouped byfunction.
Appendix	<u>Appendix A</u> Provides miscellaneous information to help you setup or use your CCU.

Typography Conventions Used

This manual uses the following Typographical conventions.

Press	Press a key, generally a movement key or function keys such as CLR.
Select	Press or adjust the indicated key or knob to obtain the desired result or display.
You see	A key word, number, or indicator that is visible on the front panel or display.
CLR	This bold font indicates a particular key on the Console Control Unit, such as the clear key in this example.
LED	This is one of the lights on the front panel. LED means Light Emitting Diode.
Key	Each of the buttons, switches, or keys on the panel that you press to cause something to happen.
Display	The 16-character alphanumeric, dot matrix, LED display.